

TORNADO



موديل
TDY-21FW

شكراً لاختيارك مجفف شعر - تورنيدو

هذه العلامة توريدو هي علامة تجارية مسجلة خاصة بشركة العربى

دليل التشغيل
مجفف شعر

ELARABY



19319 www.elarabygroup.com


Tornado

يرجى قراءة تعليمات الاستخدام هذه بعناية قبل الاستخدام، فهي تحتوي على معلومات عن السلامة، احتفظ بها للرجوع إليها فيما بعد.

ملاحظات هامة

- لا تقم بتشغيل الجهاز قبل التحقق من أن الجهد بلوحات المواصفات مماثل للجهد في منزلك.
- تجنب لف سلك التوصيل الكهربائي حول الجهاز. وتأكد دائماً من سلامة سلك التوصيل الكهربائي وخلوه من التلف.
- قم بإيقاف تشغيل الجهاز إذا لم يكن قيد الاستخدام، حتى لو كان للحظة واحدة.
- يمكن أن يستخدم الأطفال من هم في سن ٨ سنوات وما فوق هذا الجهاز، وكذلك الأشخاص ذوي القدرات الجسدية أو الحسية أو العقلية المنخفضة، أو من هم تنقصهم الخبرة والمعرفة، وذلك إذا تم الإشراف عليهم أو إذا حصلوا على التعليمات الخاصة باستخدام الجهاز بطريقة آمنة وتفهموا الأخطار الوارد حدوثها عند الاستخدام. يجب ألا يعبث الأطفال بالجهاز يجب ألا يقوم الأطفال بالتنظيف أو الصيانة دون إشراف.
- في حالة تلف سلك الإمداد، فيجب أن تستبدله من أحد مراكز خدمة العربي المعتمدة لتجنب الخطر.
- لتوفير حماية إضافية، ينصح بتركيب جهاز يعمل بالتيار المتبقي في الدائرة الكهربائية التي تزود في الحمام، بحيث ألا يتجاوز تيار التشغيل المتبقي المقدّر ٣٠ مللي أمبير.
- لا تقم أبداً بغمر المجفف في الماء .
- عند استخدام مجفف الشعر في الحمام، افصله بعد الاستخدام حيث أن قربه من الماء يمثل خطراً حتى عند إيقاف تشغيل مجفف الشعر.
- لا تستخدم هذا الجهاز بالقرب من مياه حمامات السباحة أو أحواض الاستحمام أو أي أماكن مماثلة أخرى.
- عند استخدام الجهاز، لا تجفف به أي شيء، مثل المنشفة والملابس.
- يرجى تنظيف الغبار والشعر باستخدام الفرشاة من وقت لآخر.
- يرجى تنظيف الجهاز بقطعة قماش مبللة بعض الشيء وتجفيفه بقطعة قماش جافة.

خصائص المنتج




١. مكثف هواء
٢. زر السحب
٣. شبكة فلتر قابل للفك والتركيب
٤. مفتاح تدفق الهواء البارد
٥. مقبض قابل للطي
٦. مفتاح التحكم في درجة الحرارة / السرعة
٧. سلك كهرباء قابل للسحب
٨. حلقة لسهولة التخزين

- البيانات الفنية

- القدرة: ٢٢٠-٢٤٠ فولت، تيار متغير ٥٠ / ٦٠ هرتز ~ ٢١٠٠ وات
- الملحقات: مكثف هواء
- نوع المحرك: تيار مستمر
- خاصية الأيونيز
- طول السلك: ١,٨ م


كيفية الاستخدام



- تأكد من أن يديك جافة تمامًا قبل توصيله بالكهرباء.
- قم بتوصيله بالكهرباء وضبطه على الوضع المطلوب.
- عندما يجف الشعر، قم بإيقاف تشغيل الجهاز (١) وافصل المجفف عن الكهرباء.


أ . كيفية استخدام المفتاح للتحكم في درجة الحرارة

١. تجفيف سريع |||
٢. تجفيف متوسط ||
٣. تجفيف ضعيف |
٤. إيقاف التشغيل



ب . كيف تسحب سلك الكهرباء

١. عندما تستخدم الجهاز، يمكنك سحب سلك الكهرباء حتى يظهر الشريط الأحمر.
٢. عند سحب سلك الكهرباء، يرجى الضغط على زر السحب بإصبع الإبهام
٣. وفي نفس الوقت، يرجى إمساك القابس بيدك.



ج . كيفية طي المقبض

- بعد استخدام الجهاز، يمكنك سحب سلك الكهرباء، ثم طي المقبض، لسهولة التخزين.

الأمان

- تأكد من عدم انسداد فلتر مدخلات ومخارج الهواء.
- في حالة حدوث الانسداد، فإن محدد درجة الحرارة الحراري سيمنع ارتفاع درجة الحرارة.

الضمان

- تُقدم شركة العربي ضمان لمدة سنة واحدة بدءاً من تاريخ بيع الجهاز للمستخدم النهائي.
- لا يغطي الضمان سوى العيوب في المواد المستخدمة أو التصنيع.
- يجب إجراء الصيانة بموجب الضمان في مراكز خدمة العربي المعتمدة. عند تقديم طلب بموجب الضمان، يجب تقديم فاتورة الشراء الأصلية (مع تحديد تاريخ الشراء).

لا يسري الضمان في الحالات التالية:

- الاستهلاك الطبيعي للجهاز.
- الاستخدام غير الصحيح، على سبيل المثال التحميل الزائد على الجهاز، أو إذا خضع الجهاز لأي إصلاحات من أشخاص غير معتمدين من قبل العربي واستخدام الملحقات غير أصلية.
- التلف الناتج عن تجاهل دليل المستخدم، على سبيل المثال توصيل الجهاز بسلك إمداد غير متوافق مع تعليمات التثبيت.
- فك الأجهزة بشكل كلي أو جزئي.

التخلص الصحيح من هذا المنتج

تشير هذه العلامة إلى أنه لا يجب التخلص من هذا المنتج مع النفايات المنزلية الأخرى. لمنع الضرر المحتمل على البيئة أو على صحة الإنسان من التخلص غير السليم للنفايات، تحمل مسؤولية إعادة تدويره لتعزيز إعادة الاستخدام المستدام للأجهزة.



ELARABY



19319

www.elarabygroup.Com
f Tornado

Safety

- Ensure that the air filter inputs and outputs are not blocked.
- If that does happen, thermal temperature limiter guards against overheating.

Warranty

- El Araby company provides warranty for 1 year, starting from the date on which the appliance is sold to the end user.
- The warranty only covers defects in material or workmanship.
- The repairs under warranty may only be carried out by El Araby authorized service center. when making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.

The warranty will not apply in cases of:

- Normal wear and tear.
- Incorrect use, e.g. overloading of the appliance, repairs that are undertaken by unauthorized person from El Araby or use of non-approved accessories.
- Damage caused by non-observance of the user manual, e.g. connection to an unsuitable mains supply non-compliance with the installation instructions.
- Partially or completely dismantled appliances.

Correct Disposal of This Product



This marking indicates that this product should not be disposed with other household wastes.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

ELARABY



19319

www.elarabygroup.Com


Tornado

How To Use

- Make sure that your hands are completely dry before plugging in.
- Plug in and set switch to the required position
- Once your hair is dry set the switch off (0) and unplug the dryer.


A. Switch use method

1. High Drying |||
2. Medium Drying ||
3. Low Drying |
4. OFF Setting




B. How to retract the power cord

1. When you use the appliance, you can pull out the power cord until the red tape appeared.
2. When you retract the power cord Please press the retract button by thumb.
3. and the same time, please hold the plug by hand.



C. How to fold the handle

After you used the appliance, you can retract the power cord, and then folding the handle, easy to store.




Please read this use instructions carefully before use and keep them for later reference.

Important Notice

- Do not switch on before checking that voltage on the specifications plates is the same as that in your home.
- Switch off when not in use, even if for a moment.
- If the supply cord is damaged, it must be replaced by an authorized El Araby service center in order to avoid hazard.
- Do not wrap the main cord around appliance, regularly check the main cord for wear or damage.
- For additional protection the installation of a residual current device with a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom.
- Never submerge or wet the dryer.
- ⚠ When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hair dryer is switched off.
- Do not use this appliance near water in bathtubs, basins or other vessels.
- when the appliance is using, don't jam in wind-in lid, so as towel, clothing.
- Please always disconnect your dryer before cleaning.
- Please clean the dust and hair by brush termly.
- Please clean the appliance with a slightly damp cloth and dry it up with a dry cloth.


Product Features

1. Concentrator
2. Retract Button
3. Removable filter Cover
4. Cool Shot switch
5. Foldable handle
6. Temperature /Speed Switch
7. Easy storage hook
8. Retractable power cord



- Technic Data

- Rating: 220-240V / 60Hz~2100W
- Accessories: Concentrator
- Motor type: DC Motor
- Cable : 1.8m



TORNADO

Model
TDY-21FW



Thanks for Choosing Tornado
Hair Dryer

ELARABY

19319  www.elarabygroup.com
Tornado