

TORNADO



موديل

TTM-9000

شكراً لإختيارك غلاية متعددة الاستخدامات - تورنيديو

غلاية متعددة الاستخدامات
دليل التشغيل

ELARABY

19319  elarabygroup.com
TORNADO


تعليمات آمان مهمة

- يرجى قراءة تعليمات الآمان بتمعن قبل استخدام هذا الجهاز.
١. قبل توصيل الجهاز بمصدر الكهرباء، تأكد من أن الفولتية المذكورة بالجهاز مطابقة لفولتية التيار الكهربائي في منزلك. إن لم يكن الأمر كذلك، اتصل بالبائع وتوقف عن استخدام الجهاز.
٢. تم تصميم هذا الجهاز للاستخدام المنزلي، وغير مخصص للاستخدام التجاري. يرجى عدم استخدامه في أي أغراض أخرى غير الأغراض المحددة.
٣. قم بتشغيل الجهاز فقط على سطح ثابت، ومستوي ومقاوم للحرارة. لا تميل الجهاز أبدًا لأنه قد يتسبب في انسكاب الماء الساخن من الفوهة أو فتحة تهوية البخار مما يؤدي إلى الاحتراق، أو الحروق أو حدوث إصابة أكثر خطورة.
٤. يجب وضع الجهاز في مكان بعيد عن الحائط، والأثاث والأجهزة الكهربائية الأخرى.
٥. للحماية من خطر الحريق، أو الصدمات الكهربائية أو الإصابات الشخصية، لا تغمر السلك، أو الوصلات الكهربائية أو الجهاز في المياه أو في السوائل الأخرى.
٦. يرجى توخي الحذر الشديد عند استخدام الجهاز وحمله عند الانتهاء من تسخين أو غلي المياه مباشرة.
٧. راقب فتحة البخار أو مخرج المياه أو الأسطح الساخنة الأخرى. استخدم المقبض دائمًا عند تحريك الجهاز أو رفعه، وتجنب سد فتحة البخار بأي عناصر أو أشياء أخرى.
٨. استخدم سلك الكهرباء بحذر. احرص على عدم شد السلك أو سحبه أو ثنيه، ولا تقم بتشغيل الجهاز إذا تعرض السلك للتلف بأي شكل من الأشكال. لا تقم بتوصيل الجهاز في حالة تلفه بأي شكل من الأشكال.
٩. يجب عليك دائمًا توصيل سلك الكهرباء بالجهاز أولاً ثم توصيل السلك بمأخذ التيار الكهربائي بالحائط أو بمصدر الكهرباء. لفصل الجهاز، عليك أولاً نزع القابس من مقبس الحائط أو مصدر الكهرباء.
١٠. في حالة تلف السلك الكهربائي، فيجب أن تستبدله الشركة المصنعة، أو مركز خدمة العملاء أو شخص مختص لتفادي المخاطر.
١١. لا تملأ الجهاز أبدًا أعلى من خط المؤشر لأن ذلك قد يتسبب في تناثر الماء المغلي، مما يؤدي إلى الإصابة بحروق. ولتفادي ذلك، تأكد من أن الغطاء محكم. تحذير: لا تفتح غطاء الجهاز أبدًا أثناء غلي المياه حيث سيؤدي ذلك إلى الاحتراق أو حدوث إصابات.
١٢. يرجى الانتباه إلى احتمالية تناثر الماء عندما يصل الماء إلى درجة الغليان. قد يمثل مخرج الماء الساخن أو الفوهة خطرًا لبضع لحظات بعد حدوث الغليان وبعد إيقاف تشغيل الجهاز.
١٣. هذا الجهاز مخصص لغليان الماء، لا تملأه بأي سوائل أو مواد أخرى لأن ذلك سيتلف الجهاز ويجعله غير مناسب للاستخدام مرة أخرى. ولا تقم أبدًا بتخزين الثلج في هذا الجهاز.
١٤. لا تستخدم الجهاز على الموقد، أو على صفيحة ساخنة، أو موقد طهي من أي نوع لأنه غير مصمم للتعرض للحرارة المباشرة.


تفاصيل مواصفات المنتج

١٥. راقب الأطفال عندما يكون الجهاز قيد الاستخدام. لا تضع الجهاز في أي مكان بالقرب من حواف سطح العمل أو بطريقة تسمح لسلك الكهرباء أن يتدلى. قد يسمح ذلك للطفل بإمساك الجهاز أو سحبه لأسفل من المنضدة حيث يمكن أن تحدث إصابات وحروق.
١٦. لا تلمس السطح الساخن. استخدم المقبض أو الزر.
١٧. يجب عدم غمر هذا الجهاز.
١٨. يجب توخي الحذر الشديد عند نقل الجهاز وبه ماء ساخن.
١٩. تأكد دائمًا من أن الغطاء مغلق ولا تفتحه أثناء غلي المياه. قد تحدث حروق إذا تم فتح الغطاء أثناء دورات الغليان.
٢٠. لا يمكن تحريك هذا الجهاز عند توزيع المياه.
٢١. لا يمكن للأشخاص (بما فيهم الأطفال) ذوي القدرات البدنية، أو الحسية، أو الذهنية المنخفضة أو من تنقصهم الخبرة والمعرفة استخدام هذا الجهاز إلا إذا كانوا تحت إشراف أو إذا حصلوا على تعليمات بشأن استخدام الجهاز من الشخص المسؤول عن سلامتهم.
٢٢. يجب الإشراف على الأطفال للتأكد من أنهم لا يعبتون بالجهاز.
٢٣. يمكن للأطفال من سن ٨ سنوات وأكبر استخدام هذا الجهاز إذا كانوا تحت إشراف أو إذا حصلوا على تعليمات بشأن استخدام الجهاز بطريقة آمنة وإذا أدركوا المخاطر التي ينطوي عليها استخدام الجهاز. يجب ألا يقوم الأطفال بإجراءات التنظيف والصيانة إلا إذا كانوا أكبر من ٨ سنوات وإذا كانوا تحت الإشراف. احتفظ بالجهاز وبالسلك بعيدًا عن متناول الأطفال أقل من ٨ سنوات.
٢٤. يجب ألا يعبت الأطفال بالجهاز.
٢٥. قد يتسبب استخدام المرفقات التي لا تنصح بها الشركة المصنعة في حدوث حريق، أو صدمات كهربائية أو إصابات شخصية.
٢٦. افصل الغلاية من الكهرباء عندما لا تكون قيد الاستخدام وقبل التنظيف. اترك الجهاز يبرد قبل تركيب أو فك الأجزاء، وقبل تنظيف الجهاز.
٢٧. إن هذا الجهاز معد للاستخدام المنزلي والاستخدامات المماثلة مثل:
 - مناطق مطابخ الموظفين في المحلات التجارية والمكاتب وغيرها من بيئات العمل؛
 - البيوت الريفية؛
 - يستخدمها العملاء في الفنادق، والموتيلات وغيرها من أمثلة البيئات السكنية؛
 - البيئات مثل فنادق المبيت والإفطار.
٢٨. احتفظ بهذه التعليمات.

للتبريد الامثل



لوحة التحكم



شرح استخدام الأزرار

مفتاح التشغيل

اضغط على «مفتاح التشغيل» مرة واحدة، سيبدأ الجهاز في التسخين وسيضاء مؤشر الغليان. اضغط على «مفتاح التشغيل» مرة أخرى، وسيعود الجهاز إلى وضع الاستعداد وسيومض مؤشر «مفتاح التشغيل».

زر إزالة الكلور / إعادة الغليان

أثناء عملية التسخين، اضغط على زر «إزالة الكلور / إعادة الغليان» مرة واحدة، وسيتم إلغاء خاصية إزالة الكلور / إعادة الغليان وسيستمر الجهاز في التسخين حتى يصل إلى درجة الحرارة المحددة مسبقًا. وتكون درجة الحرارة الافتراضية لتدفئة المياه هي ٤٥ درجة مئوية.

١. إذا كانت درجة حرارة الماء الحالية أقل من ٤٥ درجة مئوية، فسيتم تسخين الماء إلى ٤٥ درجة مئوية.

٢. إذا كانت درجة حرارة الماء الحالية أكثر من ٤٥ درجة مئوية، فإن الماء سوف يبرد تلقائيًا حتى يصل إلى ٤٥ درجة مئوية.

في وضع الاحتفاظ بالمياه دافئة، اضغط على الزر «إزالة الكلور / إعادة الغليان» مرة واحدة، سيدخل الجهاز في وضع التسخين ويستمر في التسخين حتى يغلي الماء.

ملحوظة: إن خاصية «إزالة الكلور / إعادة الغليان»، التي تعد طريقة لتسخين الماء إلى درجة حرارة محددة تناسب فقط المياه الجاهزة للشرب مباشرة. في حالة استخدام ماء الصنبور، لا ينصح باستخدام هذه الطريقة التسخين، وإلا ستشرب الماء غير المغلي. تستخدم هذه الخاصية فقط لتسخين المياه بطريقة صحيحة وهي مياه الصنبور الصالحة للشرب أو مياه نقية بدلًا من غليان الماء.

ملحوظة: لا يمكن إيقاف زر «إزالة الكلور / إعادة الغليان» يدويًا أثناء الاستخدام.

زر ضبط درجة الحرارة

تشمل درجات الحرارة الاختيارية ٤٥ و ٥٥ و ٨٥ و ٩٥ درجة مئوية، والإعداد الافتراضي لدرجة الحرارة هو ٤٥ درجة مئوية.

ملحوظة: درجة الحرارة المحددة هي درجة الحرارة المطلوبة للحفاظ على المياه دافئة، ولا يمكن تغيير درجة حرارة الماء في التجويف الداخلي على الفور بعد ضبط الإنهاء.

زر قفل الأمان وزر التوزيع

اضغط على زر «قفل الأمان» لإلغاء القفل وسيضاء المؤشر المقابل له باللون الأحمر، وسوف ينطفئ المؤشر بعد ٥ ثوانٍ دون الضغط على زر «التوزيع».

اضغط على زر «التوزيع» وسيضاء المؤشر المقابل باللون الأخضر، ثم سيتم توزيع المياه. وسوف ينطفئ مؤشر زر «التوزيع» عند تحرير زر «التوزيع»، وبعد ٥ ثوانٍ، سينطفئ مؤشر زر «قفل الأمان» وسيتم قفل الجهاز مرة أخرى. في ذلك الوقت، لن يعمل الضغط على زر «التوزيع». لن يعمل زر «التوزيع» إذا لم يتم الضغط على زر «قفل الأمان» في أي وقت.

مواصفات المنتج

١. سعة كبيرة ٤,٠ لتر، مع درجات حرارة اختيارية للحفاظ على المياه دافئة.
٢. ترموستات عالي الجودة، احتياطات متعددة للسلامة، وأكثر استقراراً.
٣. مع خاصية قفل الأمان لتجنب الاحتراق نتيجة سوء الاستخدام.
٤. التجويف الداخلي من الاستانلس ستيل SUS٣٠٤، مضاد للتآكل ومضاد للبكتيريا، سهل التنظيف، صحي وصديق للبيئة، يتوافق مع معايير الغذاء.
٥. تكنولوجيا المايكروكمبيوتر وتكنولوجيا التحكم في تحويل التردد الأوتوماتيكي، حفظ المياه دافئة بطاقة منخفضة، وتوفير الطاقة وحماية البيئة.
٦. مزود بلوحة تحكم كبيرة لسهولة التشغيل ووضوحه.
٧. مزود بمقبض محمول لتحريك سهل ومريح، لا يشغل مساحة.
٨. مزود بغطاء علوي قابل للإزالة لسهولة التنظيف.
٩. خاصية الحماية من الغليان الجاف.
١٠. مزود بخاصية إزالة الكلور لإزالة الكلور المتبقي في ماء الصنبور.
١١. خاصية الكشف التلقائي عن ارتفاع درجة الحرارة.

قبل استخدام غلاية الماء وجهاز التدفئة

إذا كنت تستخدم الجهاز لأول مرة، فننصحك أن تقوم بتنظيف جهازك قبل الاستخدام عن طريق غلي السعة القصوى للمياه مرة أو مرتين ثم التخلص من الماء. امسح السطح بقطعة قماش مبللة.

ملحوظة: السعة القصوى للجهاز هي ٤,٠ لتر.

استخدام غلاية المياه الكهربائية وجهاز التدفئة

١. اضغط على مقبض الغطاء العلوي ثم اسحب الغطاء العلوي لأعلى لفتحه.
٢. املأ التجويف الداخلي بماء لا يتجاوز السعة القصوى للجهاز باستخدام حاوية أخرى. من فضلك لا تدع الجسم الرئيسي يتل عند ملء الماء. بعد ملء الماء، قم بإغلاق الغطاء العلوي بإحكام.

ملحوظة: لا تملأ الجهاز بالماء أكثر من الحد الأقصى، حيث قد ينسكب الماء من مخرج الماء عند الغليان. تأكد من أن الغطاء العلوي مثبت بإحكام في مكانه قبل توصيل مصدر التيار الكهربائي.

تنبيه: يجب عدم تنشيط الجهاز قبل ملء الماء.

٣. أولاً، قم بإدخال سلك الكهرباء في مقبس جسم الغلاية الرئيسي، ثم قم بتوصيل قابس سلك الكهرباء بمصدر الكهرباء، سيومض مؤشر «مفتاح التشغيل».
٤. اضغط على «مفتاح التشغيل» مرة واحدة، سيبدأ الجهاز في تسخين الماء. إذا لم يتم اختيار درجة حرارة الاحتفاظ بالمياه دافئة، فسيدخل الجهاز في حالة الاحتفاظ بالدفء وسيظل دافئاً عند درجة الحرارة الافتراضية التي تبلغ ٤٥ درجة مئوية بعد غلي الماء، وسيضاء مؤشر الاحتفاظ بالمياه دافئة عندما يكون الجهاز في حالة الاحتفاظ بالمياه دافئة.

ملحوظة: يرجى عدم لمس جسم الغلاية الرئيسي لتجنب الاحتراق لأنه قد يصبح ساخناً أثناء التسخين.

٥. يمكنك تحديد درجة الحرارة للتدفئة وفقًا لمتطلباتك، وتشمل درجات الحرارة الاختيارية ٤٥، و٥٥، و٨٥ و٩٥ درجة مئوية. عند تحديد درجة الحرارة المطلوبة للتدفئة، سيضاء المؤشر المقابل لها.

٦. أثناء التسخين، اضغط على زر «إزالة الكلور / إعادة الغليان» مرة واحدة، سيتوقف الجهاز عن التسخين ويدخل في وضع التدفئة. إذا كنت ترغب في إعادة غلي الماء في وضع التدفئة، اضغط على زر «إزالة الكلور / إعادة الغليان» مرة واحدة، وسيضاء مؤشر الغليان وسيدخل الجهاز في وضع التسخين ويستمر في التسخين حتى يغلي الماء.

٧. عندما تحتاج إلى توزيع المياه، اضغط أولاً على زر «قفل الأمان» لفتح الجهاز، ثم اضغط مع الاستمرار على زر «التوزيع» لتوزيع المياه. وبعد ١٠ دقائق ثوانٍ من تحرير زر «التوزيع»، سينطفئ مؤشر زر «قفل الأمان» وسيتم قفل الجهاز مرة أخرى.

ملاحظات:

- (١) لا توزع الماء أثناء غليه أو في غضون ٥ دقائق بعد غليان الماء.
- (٢) لا يجوز تحريك الجهاز أثناء توزيع الماء.
- (٣) قد يكون من الصعب أحياناً توزيع الماء الساخن وذلك بسبب وجود بعض الفقاعات التي تنتج بعد غليان الماء لبعض الوقت وتدخل داخل المضخة. في ذلك الوقت، يجب أن تفتح الغطاء العلوي ثم تغلقه مرة أخرى، وعندها تختفي هذه الظاهرة. يرجى الحذر من البخار الساخن عند فتح الغطاء العلوي.
- (٤) يرجى إعادة ملء التجويف الداخلي بالماء إذا كان الماء أقل من المستوى الأدنى لمنع تشغيل التجويف الداخلي بدون ماء.
٨. بعد الانتهاء من العمل، افصل قابس سلك الكهرباء من مصدر الكهرباء ثم انزع السلك من مقبس جسم الغلاية الرئيسي.
٩. افصل الغطاء العلوي لتفريغ المياه المتبقية في التجويف الداخلي باتباع ما يلي: اسحب الغطاء العلوي أثناء الإمساك بمقبض الغطاء العلوي، واضغط على قفل الغطاء العلوي لسحب الغطاء العلوي بشكل مائل إلى الأعلى. لتركيب الغطاء العلوي، قم بتثبيت عمود الدوران بالغطاء العلوي في فتحة التثبيت بالغطاء العلوي. تأكد من عدم وجود ماء في التجويف الداخلي في حالة عدم استخدام الجهاز.
١٠. يجب تنظيف الجهاز وتجفيفه جيداً وحفظه في كيس بلاستيك عند تخزينه.

خاصية الحماية من الغليان الجاف

إذا قمت بتشغيل الغلاية بدون مياه عن طريق الخطأ، تقوم خاصية الحماية من الغليان الجاف بفصل مصدر الكهرباء أوتوماتيكياً لتجنب التسخين الزائد.

التنظيف والصيانة

ملحوظة: لا يمكن تنظيف الجهاز في غسالة الأطباق أو بمجفف أدوات المائدة.

تنظيف جسم الغلاية والغطاء العلوي

١. امسح جسم الغلاية الرئيسي والغطاء العلوي بقطعة قماش رطبة.
٢. لا تشطف الجسم الرئيسي بالماء، وإلا فقد يتدفق الماء إلى داخل الجسم الرئيسي من القاع ومنفذ الماء مما يجعل الأجزاء الإلكترونية الداخلية تبتل.

٣. لا تستخدم المنظفات للتنظيف، وإلا ستترك رائحة كريهة.
٤. لا تستخدم البنزين أو زيت التربنتين للتنظيف، وإلا فإنه قد يتلف السطح.

تنظيف التجويف الداخلي

١. امسح التجويف الداخلي بإسفنجة لينة مغموسة في المياه.
٢. لا تستخدم المنظفات، أو فرشاة العشب أو فرشاة النايلون للتنظيف.

الحلقة المانعة للتسريب

يتم استبدال الحلقة المانعة للتسريب الخاصة بالغطاء العلوي بحلقة جديدة في حالة كسرها لمنع تسرب البخار من مصفاة الغطاء العلوي. يمكن إزالة الحلقة المانعة للتسريب مباشرة.

إزالة الرواسب المعدنية

أثناء تشغيل الجهاز، ستلتصق التركيبات المعدنية مثل الكالسيوم الموجود في المياه بالزجاجة والفلتر، وهو ما يسمى «القشور» وهي غير ضارة بجسم الإنسان. وللحفاظ على أداء الجهاز، يرجى تنظيفه كل ٢-٣ أشهر باستخدام مزيل الترسبات أو حمض الستريك.

١. يرجى التأكد من أن التجويف الداخلي مزود بفلتر.
٢. أضف المنظفات أو حامض الستريك في التجويف الداخلي. إن كمية مزيل الترسبات أو حامض الستريك هي ٢٠ جرام لكل لتر من المياه.

٣. املاً التجويف الداخلي بالماء البارد إلى أقصى مستوى ثم امزج المحلول جيداً.
٤. قم بتوصيل الجهاز بمصدر الكهرباء وقم بتنشيط الجهاز لتسخين المحلول حتى يغلي. يرجى الضغط على الزر «إزالة الكلور / إعادة الغليان» لتكرار عملية التسخين إذا لم تتم إزالة الاتساخ الموجود داخل التجويف الداخلي تمامًا.

٥. افصل الجهاز من الكهرباء وافصل الغطاء العلوي لتفريغ المياه المتبقية في التجويف الداخلي.
٦. أعد ملء التجويف الداخلي بالماء البارد وقم بتنشيط الجهاز مرة أخرى لغلي الماء. كرر العملية عدة مرات حتى تزول رائحة مزيل الترسبات أو حامض الستريك.

ملحوظة: يرجى اتباع التعليمات الموجودة على عبوة مزيل الترسبات أو حمض الستريك عند التشغيل.

التخلص من الجهاز الصديق للبيئة



يمكنك المساعدة في حماية البيئة!
يرجى تذكر احترام القوانين المحلية: تُسلم الأجهزة الكهربائية التي لا تعمل إلى مركز التخلص من النفايات المناسب.

4. Do not use gasoline or turpentine for cleaning, otherwise, it will damage the surface.

Clean the inner cavity

1. Wipe the inner cavity with a plastic sponge dipped with water.
2. Do not use detergent, grass brush or nylon brush for cleaning.

Sealing ring

The sealing ring of top lid shall be replaced with a new one if it is broken to prevent the steam from leaking from the clearance of top lid. The sealing ring can be removed directly.

REMOVAL OF MINERAL DEPOSITS

During the operation of the appliance, the mineral composition such as calcium in the water will be attached to the bottle and filter, which is called «scale» and harmless to human body. In order to maintain the performance of the appliance, please clean it every 2-3 months with descaler or citric acid.

1. Please make sure that the inner cavity has been equipped with filter.
2. Add detergent or citric acid in the inner cavity. The amount of descaler or citric acid is 20g per liter of water.
3. Fill the inner cavity with cold water to the maximum level and then blend the solution completely.
4. Connect the appliance with power source and activate the appliance to heat the solution until it is boiled. Please press the “Dechlorination/Reboil” button to repeat the heating process if the dirt inside the inner cavity is not removed completely.
5. Unplug the appliance, and detach the top lid to empty the residual water in the inner cavity.
6. Refill the inner cavity with cold water and activate the appliance again to boil the water. Repeat for several times until the smell of descaler or citric acid is removed.

NOTE: Please follow the instructions on the package of descaler or citric acid when operating.

ENVIRONMENT FRIENDLY DISPOSAL

You can help protect the environment!
Please remember to respect the local regulations:
hand in the non-working electrical equipments to an
appropriate waste disposal center.



ELARABY

19319  elarabygroup.com
 **TORNADO**

6. During the heating process, press the “Dechlorination/Reboil ” button once, the appliance will stop heating and enter into the keep-warm condition. If you want to reboil the water under the keep-warm condition, press the “Dechlorination/Reboil ” button once, the boiling indicator will light up and the appliance will enter into heating mode and keep heating until the water boils.

7. When you need to dispense water, firstly press the “Safety lock” button to unlock the appliance, and then hold and press the “Dispense” button to dispense water. After releasing the “Dispense” button for about 10 seconds, the indicator of “Safety lock” button will extinguish and the appliance will be locked again.

NOTES:

(1) Do not dispense water when the water is boiling or within 5 minutes after the water is boiled.

(2) The appliance shall not be moved when the water is dispensing.

(3) It may hard to dispense hot water sometimes, that is because there is some bubble produced after the water is boiled for some time enter into the pump. At that time, you shall open the top lid and then close it again, and then this phenomenon will disappear. Please pay attention the hot steam when opening the top lid.

(4) Please refill the inner cavity with water if the water is lower than the minimum level to prevent the inner cavity from being operated without water.

8. After finish working, disconnect the plug of power cord from the power source and then remove the power cord from the socket of main body.

9. Detach the top lid to empty the residual water in the inner cavity by following the operation as below: Pull the top lid while holding the handle of top lid, and press the lock of top lid to slantwise pull the top lid upwards. To replace the top lid, fix the rotation shaft of top lid into the fixing slot of top lid. Make sure there is no water left in the inner cavity if the appliance is not used.

10. The appliance must be cleaned and dried completely and packed with plastic bag when being stored.

BOIL-DRY PROTECTION

If you accidentally let the appliance operate without water, the boil-dry protection will automatically switch off the power to avoid overheating.

CLEANING AND MAINTENANCE

NOTE:The appliance can not be cleaned with dishwasher or tableware dryer.

Clean the main body and top lid

1. Wipe the main body and top lid with a wet cloth.

2. Do not rinse the main body with water, otherwise, the water may flow into the inside of the main body from the bottom and water outlet to make the internal electronic parts be wetted.

3. Do not use detergent for cleaning, otherwise, it will leave a bad smell.

PRODUCT FEATURES

1. 4.0L large capacity, with optional keep-warm temperatures.
2. High-quality thermostat, multiple safety protection, more stable.
3. With safety lock function to avoid being burnt due to misuse.
4. SUS304 stainless steel inner cavity, anti-corrosion and antibacterial, easy to clean, healthy and environment-friendly, be in compliance with food standards.
5. Microcomputer and automatic frequency conversion control technology, low-power keeping warm, energy-saving and environmental-protection.
6. With large control panel for easy and clearly operation.
7. With portable handle for easy and convenient moving, does not occupy space.
8. With removable top lid for easy cleaning.
9. Boil-dry protection function.
10. With dechlorination function for removing the residual chlorine in tap water.
11. Automatic altitude-detection function

BEFORE USING YOUR WATER BOILER AND WARMER

If you are using the appliance for the first time, it is recommended that you should clean your appliance before use by boiling the Max capacity of water once or twice and then discarding the water. Wipe the surface with damp cloth.

NOTE: The max capacity of appliance is 4.0L.

USING YOUR ELECTRIC WATER BOILER AND WARMER

1. Press down the handle of top lid and then pull the top lid upwards to open it.
2. Fill the inner cavity with water not exceeding the maximum capacity of the appliance by another container. Please do not wet the main body when filling water. After filling water, close the top lid well in position.

NOTE: Do not fill the appliance with water over the maximum level, as water may spill out of the water outlet when boiling. Ensure that the top lid is firmly in place before plugging the power outlet.

CAUTION: The appliance must not be energized before filling water.

3. Firstly, insert the power cord into the socket of main body, then connect the plug of power cord with the power source, and then the indicator of "Power switch" blinks.
4. Press the "Power switch" once, the appliance starts to heat the water. If the keep-warm temperature is not selected, the appliance will enter into the keep-warm condition and keep warm under the default temperature of 45° C after the water being boiled, and the keep-warm indicator will illuminate when the appliance is under the keep-warm condition.

NOTE: Please do not touch the main body to avoid being burnt as it may become hot during heating process.

5. And you can select the keep-warm temperature according to your demand, the optional temperatures include 45° , 55° , 85° and 95° . When the required keep-warm temperature is selected, its corresponding indicator will illuminate.

And the default keep-warm temperature is 45° C.

1. If the current water temperature is less than 45° C, the water will be heated to 45° C.
2. If the current water temperature is more than 45° C, the water will cool down automatically to 45° C.

Under the keep-warm condition, press the “Dechlorination/Reboil ” button once, the appliance will enter into heating mode and keep heating until the water boils.

NOTE: The “Dechlorination/Reboil ” function, which is a way of heating the water to a specified temperature, is only suitable for the water that can be directly drunk. If tap water is used, this heating method is not recommended, otherwise you will drink water that is not boiled. This function is only used for properly heating the water which is drinkable tap water or pure water instead of boiling the water.

NOTE: The “Dechlorination/Reboil ” button cannot be switched off manually during use.

Temperature setting button

The optional temperatures include 45° , 55° , 85° and 95°, and the default temperature setting is 45° C.


NOTE: The temperature selected is the temperature for keeping warm, and the temperature of the water in the inner cavity can not be changed immediately after finish setting.

Safety lock button & Dispense button


Press down the “Safety lock” button to cancel the locking condition and its corresponding indicator will light up in red, and the indicator will extinguish 5 seconds after without pressing the “Dispense” button.

Press down the “Dispense” button and its corresponding indicator will light up in green, then the water is dispensed. And the indicator of “Dispense” button will extinguish when release the “Dispense” button, after 5 seconds, the indicator of “Safety lock” button will turn off and the appliance will be locked again. At that time, the “Dispense” button is invalid. The “Dispense” button will not function if the “Safety lock” button is not pressed down at any time.

KNOW YOUR WATER BOILER AND WARMER



CONTROL PANEL



BUTTON DESCRIPTION

Power switch

Press the “Power switch” once, the appliance starts to heat and the boiling indicator lights up. Press the “Power switch” again, the appliance goes back to the standby mode and the indicator of “Power switch” blinks.

Dechlorination/Reboil button

During the heating process, press the “Dechlorination/Reboil ” button once, the Dechlorination/Reboil function will be canceled and the appliance will keep heating until the preset temperature is reached.

liquids or materials as this will damage the appliance and make unsuitable for further use. And never store ice with this appliance.

14. Do not use the appliance on a stove top burner, hot plate, or cooker of any kind as it is not designed for exposure to direct heat.

15. Be aware of children when the appliance is in use. Do not position the appliance anywhere near countertop edges or in a way that allows the power cord to hang freely. This may allow a child to grab or pull the appliance down from the counter where injury and scalding can occur.

16. Do not touch the hot surface. Use the handle or the button.

17. The appliance must not be immersed.

18. Extreme caution must be used when moving an appliance containing hot water.

19. Always ensure the top lid is closed and do not lift it while the water is boiling. Scalding may occur if the top lid is removed during the brewing cycles.

20. The appliance shall not be moved when the water is dispensing.

21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.

22. Children should be supervised to ensure that they do not play with the appliance.

23. This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.

24. Children shall not play with the appliance.

25. The use of accessories, which are not recommended by the appliance manufacturer, may result in fire, electric shock or personal injury.

26. Unplug the appliance from the outlet when not in use and before cleaning. Allow the appliance to cool before putting on or taking off parts, and before cleaning the appliance.

27. This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments.

28. Save these instructions.

IMPORTANT SAFETY INSTRUCTIONS

Read this manual thoroughly before using and save it for future reference

Please read these safety instructions carefully before using this appliance.

1. Before connecting the appliance to the power supply, check that the voltage indicated on the appliance corresponds with the voltage in your home. If this is not the case, contact your dealer and stop using the appliance.
2. This appliance is designed strictly for household use, not designed for commercial use. Please do not use it for anything other than this intended usage.
3. Only operate the appliance on a stable, flat, and heat-resistant surface. Never tilt the appliance since it may cause heated water to spill from the spout or steam vent and lead to burning, scalding or a more severe injury.
4. The appliance shall be placed at a place far away from the wall, furniture and other electrical appliances.
5. To protect against a fire, electric shock or personal injury, do not immerse cord, electric plugs or appliance in water or other liquids.
6. Please use with great caution when handling the appliance at times when it contains recently heated or boiled water.
7. Mind the steam vent, water outlet or additional hot surfaces. Always use the handle when moving or lifting the device, and avoid blocking the steam vent with any other items or objects.
8. Handle the power cord with care. Be careful not to tug, pull, or bend the cord, and do not operate the device if the cord has been damaged in any way. Do not plug in the device if it is damaged in any way.
9. You must always attach the power cord to the device first and then connect the cord to the wall outlet or power supply. To disconnect the device you must remove the plug from the wall outlet or power supply first.
10. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
11. Never fill the appliance beyond the indicator line as this may cause splashing of boiling water, leading to a burn or scalding. Ensure that the lid is secured accordingly. **WARNING:** Never open the lid of the appliance while water is boiling as this is going to lead to scalding and injury.
12. Please remain aware of the potential for splashing as water reaches a boil. The hot water outlet or spout area may represent a hazard for a few moments after boiling occurs and after the device is turned off.
13. This appliance is for the boiling of water, do not fill it with any other

TORNADO

Model
TTM-9000



Thanks for Choosing Tornado
Multi-Function Boiler

ELARABY

19319  elarabygroup.com
 **TORNADO**